DC POWER SUPPLY

INSTRUCTIONS MANUAL OF DPS-3050 & DPS-5050 :

FUNCTIONS:

1. SWITCH (ON/OFF)
2. + OUTPUT RED
3. − OUTPUT BLACK
4. GROUNDING
5. AC FUSE
6. CURRENT ADJUST
7. V. (OUTPUT) ADJUST (FINE TURNING)
8. V. (OUTPUT) ADJUST
9. V. METER
10. CURRENT (A.) METER
11. OVERLOAD LIGHT (WHEN OVERLOAD)
12. POWER LIGHT (POWER ON/OFF)

OPERATION INSTRUCTIONS:

1. MAKE SURE THE V. (INPUT) IS AC110V ± 5% 60HZ.
2. TURN THE SWITCH TO "ON". NO.12,THE GREEN LIGHT TURN ON. (IF NO.11 LIGHTS TURN ON, TURN NO.6 TO RIGHT A BITE,THEN NO.11 RED LIGHTS WILL TURN OFF,NO.12 GREEN LIGHTS WILL TURN ON).
3. USE NO.8 ADJUST THE VOLTAGE.
4. USE A WIRE TO SHORT CIRCUIT NO.2 & NO.3.AT THIS MOMENT YOU CAN READING "0" FROM NO.9 AND GREEN LIGHTS WILL TURN OFF.YOU CAN READING FROM NO.10 AND RED LIGHTS WILL TURN ON.
5. ADJUST NO.6,AND YOU CAN READING FROM NO.10.
6. TAKE OFF THE WIRE (NO.2 & NO.3),THEN YOU CAN READING FROM NO.10 ,AND GREEN LIGHTS WILL TURN ON.YOU CAN READING "0" FROM NO.9, AND RED LIGHTS WILL TURN OFF.
7. THE FUSE "MUST" ACCORDING THE REGULATION FOR CHANGE THE NEW FUSE. "DO NOT USE OTHER FUSE TO INSTEAD".
   * DPS-3050 IS 1.5A (FUSE)
   * DPS-5050 IS 3A (FUSE)
8. IF AN OVERLOAD OCCURS,"MUST" WAIT 15-20 SECONDS BEFORE RESETTING.THIS IS THE PROTECTION FUNCTIONS OF DC POWER SUPPLY.

0~50V~3A. 5A

DPS-3050, DPS-5050